

ALPHABETICAL INDEX

DESCRIPTION	GROUP NO.	DESCRIPTION	GROUP NO.
- A -			
ABSORBER, Dynamic	11.900	ANCHOR, Tow Start Control To Upper Lever	5.360
ABSORBER KIT, Dynamic	11.390	ANTENNA, Front Fender	15.030
ACTUATOR ASSEMBLY, Folding Top Manual Operating Counter Balance	28.050	ANTENNA, Rear Deck.....	15.030
ACTUATOR ASSEMBLY, Front Seat Cushion Lounge Tilt.....	29.140	ANTI-FREEZE	15.040
ACTUATOR, Back-Up Lamp Switch.....	3.319	ANTI-SLIP, Steering Gear Upper Jacket.....	10.338
ACTUATOR, Electric Windshield Wiper Drive Link.....	22.238	ANTI-SQUEAK, Air Intake Panel To Fender	2.051
ACTUATOR, Steering Wheel.....	10.830	ANTI-SQUEAK, Front Fender Cross Tie Baffle To Grille Panel	12.009
ADAPTER, Air Conditioning Intermediate Pulley	13.430	ANTI-SQUEAK, Front Fender To Body Pillar	12.075
ADAPTER, Clock Wire Terminal	3.378	ANTI-SQUEAK, Front Fender To Body Pillar At Side Sill	12.075
ADAPTER, Converter Housing To Cushion ..	1.013	ANTI-SQUEAK, Front Fender To Grille Panel.....	12.075
ADAPTER, Courtesy Lamp Assembly Wire ..	3.349	ANTI-SQUEAK, Front Fender To Side Sill ..	12.075
ADAPTER, E-Stick Intake Manifold	5.250	ANTI-SQUEAK, Grille Panel To Engine Front Crossmember	2.051
ADAPTER, Gear Shift Lever Boot.....	7.011	ANTI-SQUEAK, Grille Panel To Fender	2.051
ADAPTER, Headlamp Switch Wire.....	3.145	ANTI-SQUEAK, Grille Panel To Shroud.....	2.051
ADAPTER, Hydrovac Fitting	8.595	ANTI-SQUEAK, Grille Panel To Wheelhouse ..	2.051
ADAPTER KIT, Air Conditioning	15.015	ANTI-SQUEAK, Instrument Panel To Cowl Side	22.056
ADAPTER KIT, Crankshaft Pilot Bushing...	1.043	ANTI-SQUEAK, Lower Radiator Air Baffle To Fender.....	2.062
ADAPTER KIT, Power Brake.....	15.310	ANTI-SQUEAK, Radiator Support To Wheelhouse.....	2.023
ADAPTER, Life Guard Safety Tire Pressure Check.....	8.270	ANTI-SQUEAK, Side Radiator Air Baffle To Wheelhouse.....	2.062
ADAPTER, Oil Filter	1.208	ANTI-SQUEAK, Windshield Side Finish Moulding	26.001
ADAPTER, "Open Door" Warning Lamp At Fuse Panel.....	3.655	APPEARANCE SUPPLIES	15.050
ADAPTER, Overdrive Case To Torque Tube..	6.290	ARM AND LINK, Rear Deck Door Hinge.....	23.028
ADAPTER, Overdrive Housing.....	6.265	ARM ASSEMBLY, Front Suspension Upper Control.....	10.066
ADAPTER, Overdrive Rear Oil Seal	6.286	ARMATURE, Electric Windshield Wiper Motor	22.205
ADAPTER, Overdrive Vacuum Switch.....	6.368	ARMATURE, Folding Top Operating Power Unit Motor.....	28.058
ADAPTER, Power Brake Vacuum Nipple....	8.460	ARM, Bottom Frame Outer Hinge Adjusting ..	29.103
ADAPTER, Rear Air Suspension Rear Leveling Valve.....	11.365	ARM, Directional Signal Switch	3.321
ADAPTER, Speedometer Driven Gear Double Drive	3.590	ARM, Distributor Advance.....	3.030
ADAPTER, Speedometer Wire Terminal	3.550	ARM, Front Suspension Lower Control	10.045
ADAPTER, Steering Gear Shaft Lower Bearing	10.768	ARM, Front Suspension Upper Control	10.066
ADAPTER, Steering Wheel	10.280	ARM KIT, Front Suspension Lower Control ..	10.045
ADAPTER, Torque Tube.....	9.156	ARMOR, Cowl Ventilator Cable	22.018
ADAPTER, Transmission To Reverse Gear Housing.....	6.030	ARMOR, Overdrive Control Core	6.350
ADAPTER, Transmission To Torque Tube ..	6.030	ARM, Outside Rear View Mirror Head Mounting	15.270
ADAPTER, Trunk Lamp Assembly Wire Terminal	3.660	ARM, Power Brake Lever	8.665
ADJUSTER ASSEMBLY, Power Steering Gear Upper Thrust Bearing.....	10.635	ARM, Rear Deck Door Hinge.....	23.028
ADJUSTER, E-Stick Servo Self	5.302	ARM, Rear Door Electric Operated Window Regulator	23.305
ADJUSTER, Steering Gear Worm Ball Bearing	10.326	ARM, Rear Seat Back Center Armrest	29.232
AIR CONDITIONING KIT.....	15.015	ARMREST ASSEMBLY, Trimmed Front Seat Back Center	29.141
ALTERNATOR	3.005	ARMREST ASSEMBLY, Trimmed Rear Seat Back Center	29.230
ALTERNATOR	3.016	ARMREST, Door	*****
AMMETER, Alternator	3.600	ARMREST, Rear Quarter Side.....	*****
ANCHOR, Brake Pedal Return Spring	8.168	ARM, Steering Knuckle.....	10.035
ANCHOR, Brake Shoe Hold Down Spring	8.008	ARM, Steering Linkage Idler.....	10.108
ANCHOR, Clutch Beam Pull Back Spring....	5.184	ARM, Steering Linkage Pitman.....	10.104
ANCHOR, Clutch Throwout Lever Spring	5.132		
ANCHOR, Clutch Throwout Lever Spring	5.178		
ANCHOR, Clutch Throwout Lever Spring	5.190		
ANCHOR, Throttle Control Cable	4.024		

A - Cont.

***** Refer separate Upholstery parts catalog