

ALPHABETICAL INDEX

DESCRIPTION	GROUP NO.	DESCRIPTION	GROUP NO.
H - Cont.		H - Cont.	
HARNESS, Alternator.....	3.005	HINGE, Front Door Lower.....	23.016
HARNESS, Alternator To Voltage Regulator And Junction Block.....	3.016	HINGE, Front Door Upper.....	23.015
HARNESS, Automatic Transmission Solenoid Kickdown Switch Wire.....	16.245	HINGE, Glove Box.....	22.060
HARNESS, Back-Up Lamp Wire.....	3.318	HINGE, Hood.....	12.035
HARNESS, Body Wire.....	3.163	HINGE, Liftgate.....	23.011
HARNESS, Cargo Area Lamp.....	3.670	HINGE, Rear Auxiliary Floor Extension....	20.430
HARNESS, Chassis Wire.....	3.165	HINGE, Rear Auxiliary Floor Side Compartment Door.....	20.437
HARNESS, Clock Wiring.....	3.378	HINGE, Rear Deck Door.....	23.028
HARNESS, Courtesy Lamp Assembly Switch To Connector.....	3.349	HINGE, Rear Door Lower.....	23.018
HARNESS, Courtesy Lamp Assembly Switch To Domelamp Harness.....	3.349	HINGE, Rear Door Upper.....	23.017
HARNESS, Courtesy Lamp Assembly To Courtesy Lamp Assembly.....	3.349	HINGE, Rear Seat Back.....	29.221
HARNESS, Courtesy Lamp Assembly Wire...	3.349	HINGE, Spare Tire Cover Panel.....	20.450
HARNESS, Directional Signal Switch Extension Wire.....	3.321	HINGE, Spare Wheel Carrier Support.....	8.350
HARNESS, Door Electric Operated Window Regulator Wiring.....	23.320	HINGE, Tailgate Opening Panel.....	20.460
HARNESS, Folding Top Power Unit Wiring...	28.057	HINGE, Third Seat Back.....	29.260
HARNESS, Front Door Switch.....	3.163	HINGE, Third Seat Cushion.....	29.280
HARNESS, Ignition Switch To Flasher.....	3.130	HOOD.....	12.001
HARNESS, Instrument Cluster.....	3.635	HOOD, Gear Selector Dial Light.....	7.535
HARNESS, Overdrive Wire.....	3.210	HOOD, Overdrive Indicator Light.....	6.380
HARNESS, Rear Door Switch.....	3.163	HOOD, Speedometer.....	3.550
HARNESS, Rear Quarter Electric Operated Window Regulator Wiring.....	24.215	HOOK, Automatic Transmission Upper Control Valve Vacuum Control.....	16.205
HARNESS, Tailgate Electric Operated Window Regulator Wiring.....	23.320	HOOK, Base Hold Down.....	14.140
HARNESS, To Solenoid And Starter Relay...	3.130	HOOK, Coat.....	27.130
HARNESS, Vacuum Door Lock Tubing.....	23.067	HOOK, Folding Top Front Header Latch....	28.008
HAZE CREAM.....	15.050	HOOK, Hydrovac Vacuum Cylinder.....	8.585
HEAD ASSEMBLY, Cylinder.....	1.059	HOOK, Jack Lift Hold Down.....	14.138
HEAD, Electric Windshield Wiper Motor Commutator End.....	22.210	HORN, Dual.....	3.105
HEAD, Electric Windshield Wiper Motor Drive End.....	22.215	HORN KIT.....	15.202
HEADER, Folding Top Front.....	28.018	HOSE, Air Conditioning.....	13.440
HEADER, Rear Opening.....	20.390	HOSE, Air Valve Solenoid.....	5.270
HEAD, Folding Top Operating Power Unit Motor.....	28.058	HOSE, Automatic Transmission Oil Cooler Tube.....	16.230
HEADLAMP ASSEMBLY.....	3.245	HOSE, Battery Box Drain.....	3.082
HEADLINING.....	*****	HOSE, Brake Tube.....	8.116
HEADNUT, Brake Master Cylinder.....	8.050	HOSE, Carburetor Choke Heater Tube.....	4.020
HEAD, Outside Rear View Mirror.....	15.270	HOSE, Carburetor Insulator To Ventilation Valve.....	1.117
HEADPOST, Spotlight.....	15.370	HOSE, Check Valve To Hydrovac.....	8.600
HEAD, Rear Air Suspension Compressor Cylinder.....	11.303	HOSE, Cowl Ventilator Drain.....	13.115
HEADREST ASSEMBLY, Front Seat Back...	15.197	HOSE, Cylinder Block To Ventilation Valve...	1.118
HEADREST ASSEMBLY, Front Seat Back...	*****	HOSE, Cylinder Block Ventilation Valve....	1.119
HEATER.....	13.001	HOSE, Cylinder Head To Control Valve....	13.050
HEATER, Carburetor Choke.....	4.018	HOSE, Defroster.....	13.108
HEATER, Engine.....	15.145	HOSE, E-Strick Valve Body To Check Valve.	5.295
HINGE, Accelerator Pedal.....	4.040	HOSE, Folding Top Power Unit To Hydraulic Cylinder.....	28.056
HINGE ASSEMBLY, Tailgate.....	23.006	HOSE, Front Door Link Anti-Rattle.....	23.055
HINGE, Bracket To Bumper Rail.....	14.104	HOSE, Front Wheel Disc Brake.....	8.855
HINGE, Console Compartment Door.....	27.276	HOSE, Gasoline.....	4.160
		HOSE, Gasoline Tank Drain.....	4.141
		HOSE, Gasoline Tank Filler Tube Vent....	4.141
		HOSE, Heater Air Damper Vacuum.....	13.020
		HOSE, Heater Core To Tube.....	13.050
		HOSE, Heater Water.....	13.050
		HOSE, Heater Water Valve To Core.....	13.050
		HOSE, Hydrovac To Master Cylinder.....	8.600
		HOSE, Manifold To Check Valve.....	8.600
		HOSE, Oil Filler Cap To Air Cleaner.....	1.116
		HOSE, Oil Filter.....	1.198

***** Refer separate Upholstery parts catalog