

ALPHABETICAL INDEX

DESCRIPTION	GROUP NO.	DESCRIPTION	GROUP NO.
R - Cont.		R - Cont.	
REINFORCEMENT, Radiator Air Intake Center Panel	2.051	RESERVOIR, Rear Air Suspension Air	11.340
REINFORCEMENT, Radiator Air Intake Lower Panel	2.051	RESERVOIR, Windshield Washer	15.440
REINFORCEMENT, Radiator Air Intake Panel	2.051	RESISTOR, Air Conditioner Blower Motor	13.072
REINFORCEMENT, Radiator Grille	2.050	RESISTOR, Alternator	3.005
REINFORCEMENT, Rear Body Pillar	20.245	RESISTOR, Alternator	3.016
REINFORCEMENT, Rear Bumper Mounting ..	20.325	RESISTOR, Headlamp Switch Rheostat	3.145
REINFORCEMENT, Rear Bumper Mounting ..	20.330	RESISTOR, Ignition	3.065
REINFORCEMENT, Rear Fender Lower Corner	12.125	RESISTOR, Overdrive Kickdown Relay	6.365
REINFORCEMENT, Rear Quarter Body Lock Pillar	20.245	RESISTOR, Radio	15.320
REINFORCEMENT, Rear Quarter Window Front	20.273	RETAINER, Air Conditioning Air Discharge Grille	13.510
REINFORCEMENT, Rear Seat Belt Mounting	20.005	RETAINER, Air Conditioning Air Discharge Grille Door Hinge Spring	13.515
REINFORCEMENT, Rear Shock Absorber Mounting	20.038	RETAINER, Air Conditioning Air Discharge Lower Door	13.515
REINFORCEMENT, Rear Sill To Cross Sill Bumper Mount	20.070	RETAINER ASSEMBLY, Lower Air Baffle ...	2.062
REINFORCEMENT, Rear Wheelhouse To Floor Pan	20.272	RETAINER, Automatic Transmission Parking Brake Toggle Link Spring	16.090
REINFORCEMENT, Rear Window Opening ...	20.397	RETAINER, Automatic Transmission Parking Brake Toggle Lever Anchor Pin	16.090
REINFORCEMENT, Regulator Panel To Unside	20.280	RETAINER, Automatic Transmission Parking Brake Torsion Lever Pin Spring	16.090
REINFORCEMENT, Rocker Panel	20.180	RETAINER, Automatic Transmission Rear Bearing	16.175
REINFORCEMENT, Side Roof Rail	20.260	RETAINER, Automatic Transmission Rear Bearing Retainer Oil	16.175
REINFORCEMENT, Side Roof Rail To Rear Quarter Side Roof Rail	20.260	RETAINER, Automatic Transmission Rear Clutch Drum Spring	16.125
REINFORCEMENT, Side Sill Rear	20.070	RETAINER, Automatic Transmission Rear Servo Accumulator Spring	16.070
REINFORCEMENT, Side Sill To Rear Wheelhouse Filler	20.070	RETAINER, Automatic Transmission Rear Servo Piston Spring	16.070
REINFORCEMENT, Steering Gear Shaft Flange	10.715	RETAINER, Automatic Transmission Solenoid Kickdown Switch Spring	16.245
REINFORCEMENT, Tailgate Opening Pillar.	20.315	RETAINER, Automatic Transmission Throttle Control Cable	16.300
REINFORCEMENT, Tail, Stop And Rear Directional Signal Lamp Inner	3.303	RETAINER, Brake Master Cylinder Piston Cup	8.046
RELAY, Horn	3.125	RETAINER, Brake Shoe Hold Down Spring ..	8.008
RELAY, Overdrive Indicator Light	6.380	RETAINER, Brake Shoe Parking Brake Lever Strut	8.024
RELAY, Overdrive Kickdown	6.365	RETAINER, Clutch Pedal To Rod Seal	5.162
RELAY, Starting Motor	3.022	RETAINER, Clutch Pivot To Lever Boot ...	5.168
REPAIR KIT, Air Conditioning Receiver Check Valve	13.455	RETAINER, Clutch Throwout Lever Boot ...	5.125
REPAIR KIT, Brake Master Cylinder	8.048	RETAINER, Console Compartment Door Lock	27.280
REPAIR KIT, Brake Wheel Cylinder	8.080	RETAINER, Door Electric Operated Window Regulator Pinion Grease	23.308
REPAIR KIT, Front Wheel Disc Brake Caliper	8.820	RETAINER, Door Electric Operated Window Regulator Worm Grease	23.308
REPAIR KIT, Fuel Pump	4.110	RETAINER, Door Outside Handle Button ...	23.074
REPAIR KIT, Hydrovac	8.552	RETAINER, Door Trim Panel Overlay End Moulding	23.198
REPAIR KIT, Power Brake Master Cylinder .	8.512	RETAINER, Door Trim Panel Overlay End Moulding	23.205
REPAIR KIT, Power Brake Power Unit	8.405	RETAINER, Electric Windshield Wiper Drive Crank Eccentric	22.242
REPAIR KIT, Power Brake Unit	8.655	RETAINER, Engine Rear Support Crossmember To Sill Cushion	1.015
REPAIR KIT, Universal Joint Ball Stud	9.120		
REPLACEMENT KIT, Hydrovac Poppet	8.552		
RESERVOIR, Folding Top Operating Power Unit	28.058		
RESERVOIR, Power Steering Pump Oil	10.465		

***** Refer separate Upholstery parts catalog