

ALPHABETICAL INDEX

DESCRIPTION	GROUP NO.	DESCRIPTION	GROUP NO.
S - Cont.		S - Cont.	
SPRING, Clutch Pressure Lever Anti-Rattle .	5.026	SPRING, Gear Shift Operating Shaft Lever	
SPRING, Clutch Release Idler Lever	5.172	Compression	7.085
SPRING, Clutch Rod To Pedal Retaining . . .	5.160	SPRING, Gear Shift Upper Lever	7.025
SPRING, Clutch Throwout Lever	5.132	SPRING, Gear Shift Upper Lever Housing	
SPRING, Clutch Throwout Lever	5.190	Vibration Dampening	7.020
SPRING, Clutch Throwout Lever Return . . .	5.123	SPRING, Gear Shift Upper Lever Pressure	
SPRING, Cylinder Lock Retainer	23.086	Pin	7.025
SPRING, Directional Signal Switch Arm To		SPRING, Gear Shift Upper Lever Pressure	
Mounting Plate	3.321	Pin Retainer	7.025
SPRING, Directional Signal Switch Return . .	3.321	SPRING, Hand Operated Parking Brake	
SPRING, Distributor Cap Contact	3.032	Bellcrank Return	8.187
SPRING, Door Outside Handle Button Return.	23.074	SPRING, Handle Hold Down	14.142
SPRING, Door Outside Handle Trigger Return	23.074	SPRING, Headlamp Adjusting	3.272
SPRING, Door Window Regulator Handle		SPRING, Heater Air Damper Idler Lever	
Tension	23.100	Return	13.017
SPRING, Electric Windshield Wiper Drive		SPRING, Heater And Defroster Control	13.017
Crank Eccentric	22.242	SPRING, Heater Damper And Water Valve	
SPRING, Engine Oil Pump Release Valve . .	1.176	Lever Detent	13.017
SPRING, E-Stick Actuator Cam Pivot		SPRING, Hood Hinge	12.048
Compression	5.335	SPRING, Hood Lock	12.060
SPRING, E-Stick Actuator Cam Stop	5.327	SPRING, Horn Blowing Ring	3.406
SPRING, E-Stick Servo Piston Assembly . . .	5.315	SPRING, Horn Blowing Ring Contact	3.406
SPRING, Exhaust Manifold Damper Heat		SPRING, Horn Button	3.416
Valve Anti-Flutter	1.067	SPRING, Horn Button Contact	3.400
SPRING, Foot Operated Parking Brake		SPRING, Hydrovac Air Cleaner Poppet Valve	8.555
Return	8.180	SPRING, Hydrovac Hydraulic Master Piston	
SPRING, Front Coil	11.072	Ball	8.575
SPRING, Front Door Electric Operated		SPRING, Hydrovac Hydraulic Piston	8.580
Window Regulator Balance	23.300	SPRING, Hydrovac Hydraulic Piston Seal . . .	8.580
SPRING, Front Door Link Anti-Rattle	23.055	SPRING, Hydrovac Piston	8.570
SPRING, Front Door Lock Contact Lever		SPRING, Hydrovac Relay Valve Return	8.570
Return	23.050	SPRING, Jack Hold Down	14.138
SPRING, Front Door Lock Trip Lever Return.	23.050	SPRING KIT	14.112
SPRING, Front Door Upper Hinge	23.015	SPRING KIT, Exhaust Manifold Damper Heat	
SPRING, Front Door Ventilator Lock Handle		Valve Anti-Flutter	1.067
Button	23.121	SPRING KIT, Foot Operated Parking Brake	
SPRING, Front Seat Adjusting Slide	29.138	Lever	8.180
SPRING, Front Seat Adjusting Slide		SPRING KIT, License Frame	15.240
Latch Wire Tension	29.133	SPRING KIT, Rear Axle Differential Preload.	9.038
SPRING, Front Seat Back	29.106	SPRING, License Plate Lamp Socket	3.341
SPRING, Front Seat Center Cushion	29.157	SPRING, Liftgate Bracket	23.034
SPRING, Front Seat Cushion	29.162	SPRING, Liftgate Handle	23.078
SPRING, Front Seat Cushion Lounge Tilt		SPRING, Load Leveler	11.235
Actuator	29.140	SPRING, Locking Gas Cap Lock Bolt Cone . .	15.180
SPRING, Front Seat Cushion Lounge Tilt		SPRING, Lower Baffle Retaining	1.108
Actuator Release	29.140	SPRING, Outside Rear View Mirror Glass . .	15.270
SPRING, Front Seat Slide Adjuster Latch		SPRING, Overdrive Kickdown Switch	6.367
Locking	29.131	SPRING, Overdrive Kickdown Switch	
SPRING, Fuel Pump Filter Bowl	4.110	Contact Plate	6.366
SPRING, Gasoline Filter Magnet	15.190	SPRING, Overdrive Kickdown Switch	
SPRING, Gasoline Filter Magnet And Filter .	15.190	Retainer	6.367
SPRING, Gear Shift Lever Anti-Rattle	7.001	SPRING, Overdrive Roller Set Retaining . . .	6.332
SPRING, Gear Shift Lever Pivot Shaft		SPRING, Overdrive Shift Rail Retractor	6.295
Compression	7.005	SPRING, Overdrive Shift Rail Reverse	
SPRING, Gear Shift Lever Return	7.001	Lockup	6.295
SPRING, Gear Shift Lower Lever	7.001	SPRING, Parking Brake Lever Strut	8.008
SPRING, Gear Shift Operating Shaft	7.039	SPRING, Parking Brake Rear Cable	
SPRING, Gear Shift Operating Shaft Lever		Retaining	8.220
Centering	7.085	SPRING, Parking Brake Warning Lamp	3.650
		SPRING, Power Brake Air Valve Return	8.685

***** Refer separate Upholstery parts catalog