

KEY NO.	HOLLEY NO.	A.M. NO.	DESCRIPTION	PER CAR
41	13R-490		Secondary Throttle Shaft Bushing	3
42	14R-320	320 6382	Fuel Line Tubing	1
43	15R-40	320 2206	* Idle Adjusting Needle	2
44	16R-258A	320 2208	@ Float and Hinge Assembly	2
45	18R-50A	320 2210	#*@ Fuel Valve and Seat Assembly	2
46	19R-74		Spark Fitting	1
47	19R-92	320 6385	@ Fuel Inlet Fitting	1
48	19R-189	320 3160	φW Pump Lever Adjusting Screw Fitting	1
49	21R-572-21	320 3187	* Pump Discharge Nozzle	1
50	22R-40-35	320 3162	* Main Jet (Secondary)	2
51	22R-40-49	320 3163	* Main Jet (Primary)	2
52	23R-196	320 3168	φ Bowl Vent Valve	1
53	23R-211	320 3169	φ@ Air Vent Valve	1
54	25R-237A-85	320 2215	#* Power Valve Assembly	2
55	27R-109	320 2216	#+@° Fuel-Line Tube "O" Ring	2
56	27R-152		#+ Idle Needle Seal	2
57	27R-238		#+H Choke Rod Seal	1
58	28R-1	320 3175	φ*H Check Ball	1
59	28R-35	320 6387	* Pump Check Ball	1
60	28R-94	320 3181	φ* Pump Check Ball	1
61	34R-1334		H Diaphragm Cover	1
62	34R-1529A		Z Choke Housing and Plugs Assembly	1
63	34R-2568A		@ Fuel Bowl and Plugs Assembly (Complete)(Primary)	1
64	34R-3038A		@ Fuel Bowl and Plugs Assy. (Complete)(Secondary)	1
65	34R-2183A		@X Fuel Pump Cover Assembly	1
66	34R-1940A	320 3708	Main Metering Body & Plugs Assembly (Primary)	1
67	34R-1942A	320 3709	Main Metering Body & Plugs Assembly (Secondary)	1
68	35R-199A	320 2217	*H Secondary Diaphragm Assembly	1
69	35R-342A	320 2218	#*@X Diaphragm Assembly	1
70	36R-164	320 3183	φ*H Secondary Diaphragm Link Retainer	1
71	36R-169	320 3189	φ*@ Air Vent Rod Spring Retainer	1
72	36R-225	320 3190	φ*@ Air Vent Valve Retainer	1
73	36R-236	320 6388	*@ Float Retainer	2
74	38R-108	320 3191	φ Fast Idle Adjusting Screw Spring	1
75	38R-110	320 3192	φW Throttle Stop Screw Spring	1
76	38R-464	320 3195	φH Secondary Diaphragm Spring	1
77	38R-569	320 3196	φ@X Diaphragm Return Spring	1
78	38R-583	320 3197	φW Fast Idle Cam Lever Spring	1
79	38R-587	320 3198	φW Pump Lever Adjusting Screw Spring	1
80	38R-607		Throttle Return Spring	1
81	38R-615	320 3199	φ@ Air Vent Rod Spring	1
82	38R-616	320 6389	@ Float Spring	2
83	38R-635	320 6390	* Pump Check Ball Retainer	1
84	39R-5	320 6344	Z Choke Shaft Nut	1
85	40R-108	320 3208	φZ Choke Thermostat Lever Spacer	1
86	40R-336	320 6391	Pump Check Ball Weight	1
87	41R-244A	320 6392	Z Fast Idle Cam Assembly	1
88	41R-234	320 6393	Pump Cam (Black)(Used on 60 80, Except Carb, 320 2368, R-1312-2 And R-1957-1)	1
88	41R-240	320 6347	Pump Cam (Red)(Used on 60 20)(Also Used on 60 80 With Carb. 320 2368, R-1313-2 And R-1957-1)	1
89	43R-203		H Choke Rod	1
90	43R-205		W Throttle Connecting Rod	1
91	43R-219	320 6394	@ Air Vent Push Rod	1
92	46R-25	320 6396	W Throttle Connecting Rod Washer	1
93	46R-248	320 6349	Z Choke Shaft Nut L.W.	1
94	46R-463		Choke Rod Seal Washer	2
95	47R-10A	320 3222	Z Thermostat Housing Assembly	1
96	48R-31	320 3227	φ*H Choke Rod Retainer	2
97	48R-183	320 3228	φ*W Throttle Connecting Rod Retainer	2