

Group No. 1.151, Page No. Gr 1 - 47, On Part Number 316 9972, Change Listing To Read:

64-65 01 (LHE)(OHVC-196): 64 10 (OHVC-196)..... 1 316 9972

Group No. 5.160, Page Gr 5 - 12, Delete The First Eight Listings At The Top Of The Page From The Parts Catalog. The Part Numbers Are: 316 2381, 315 7648, 317 3455, 316 7615, 317 2549, 317 2570, 317 4788 And 318 1763.

Group No. 5.160, In Place Of The First Eight Deleted Listings, Add The Following Twelve Parts Listings.

61 20 (Note 5.160-2) ..... 1 316 2381  
60-61 80 ..... 1 315 7648  
62 80 ..... 1 316 3459  
**62 10 (WST-Heavy Duty-Note 5.001-1)** ..... 1 316 4200  
64 10 (V8-Note 5.160-3 Type 2, Note 5.168-5): 65 10 (OHV-232)(V8-Note  
5.168-5): 64-65 80 (Note 5.168-5) ..... 1 317 3455  
63 Thru 65 10-80 (V8-WCGS-Note 5.168-6) ..... 1 318 1763  
64 10 (LHD-Six): 65 10 (OHV-199-LHD) ..... 1 317 2549  
**60-61 10 (RHD)** ..... 1 314 8942  
**62 10 (RHD)** ..... 1 316 3680  
**63 10 (RHD)** ..... 1 316 7615  
**64 10 (RHD-SIX)** ..... 1 317 2570  
**65 10 (RHD-OHV-232)** ..... 1 317 4788

Group No. 5.160, Page Gr 5 - 12, After Part Number 315 8566, SEAL, Lever To Rod, Six Parts Listings Of "RODS" Were Incorrectly Inserted, Delete These Six Listings From The Parts Catalog. The Part Numbers Are: 316 4200, 318 4942, 316 3680, 315 7650, 315 7648 And 316 3459.

Group No. 6.001, Page No. Gr 6 - 1, On Part Number 320 6565, Change Listing To Read:

64-65 10 (LHD-OHV-232-WST): 65 80  
(LHD-OHV-232-WST).....(Replaces 320 5222) ..... 1 320 6565

Group No. 6.001, Page No. Gr 6 - 1, After Part Number 320 6565, Insert The Following Listing:

**65 10 (RHD-OHV-232-WST-WCGS)** ..... 1 320 6566

Group No. 6.001, Page No. Gr 6 - 1, On Part Number 317 6498, Change Listing And Part Number To Read:

**65 10 (RHD-OHV-232-WST)** ..... (Use 320 6566) ..... 1 317 6499

Group No. 6.001, Page No. Gr 6 - 2, Part Numbers 320 6783 And 320 6753, Are Each Listed Twice: Delete All Information On All Four Listings From The Parts Catalog:

Group No. 6.001, Page No. Gr 6 - 3, On Part Number 317 6499, Change Listing And Part Number To Read:

**65 10 (RHD-OHV-232-WOD)** ..... 1 317 6498

Group No. 6.005, Page No. Gr 6 - 5, On Part Number 320 6189, Change Listing To Read:

63 10 (V8-287): 64-65 10 (V8-287-WOD)(V8-287-WST-Note 6.017-2 Type 1 & 3):  
64-65 10 (OHV-232-WOD)(OHV-232-WST): 65 80 (OHV-232-WOD)  
(OHV-232-WST)(V8-287-WOD)(V8-287-WST-Note 6.017-2  
Type 3) .....(Replaces 317 1337) ..... 1 320 6189

Note No. 6.017-2, Page No. Gr 6 - 6, Change The 1st. Line Of Note 6.017-2 To Read:

NOTE 6.017-2: Three Types of Transmissions were used on the 64-65 10 (WST). They can be identified as

Group No. 6.052, Page No. Gr 6 - 11, After Part Number 310 8320, Insert The Following Listing:

60 Thru 65 01-10 (Six-WOD) ..... 6.040 1 315 6627

Group No. 6.052, Page No. Gr 6 - 11; On Part Number 312 1135, Change Listing To Read:

63 10 (V8-WST)(V8-WOD): 64 10 (V8-287-WST-Note 6.017-2 Types 1 And 3) ... ..... 1 312 1135