

GROUP NO. — DESCRIPTION — YEAR and MODEL	PRIMARY GROUP NO.	PER CAR	PART NO.	CODE
Dole (150 Deg.) 61 Thru 64 01 (Export Only): 61 Thru 64 10 (OHVC-196-Export Only): 65 01 (LHE)(OHV-196).....(Replaces 320 4600)	1	320 3468	
Dole (167-172 Deg.) 60-61 01 (OHV): 60 10: 61 10 (OHVC): 60-61 20-80.....(Use 320 3273)	1	320 1255	
Dole (167-173 Deg.) 60-61 01: 60 10: 61 10 (OHVC).....(Use 320 3273)	1	320 1249	
Dole (177-182) Deg.) 60-61 01: 60 10: 61 10 (OHVC).....	1	320 3273	
Dole (177-182 Deg.) 60-61 20-80.....(Use 320 3273)	1	320 1254	
Dole (192-197 Deg.) 60 Thru 64 01: 65 01 (LHE)(OHV-196): 61 Thru 64 10 (OHVC-196).....	1	320 5798	
Dole (192-197 Deg.) 65 01 (OHV-199) (OHV-232): 61 Thru 64 10 (OHVA): 64 10 (OHV-232): 65 10 (Six): 65 80 (OHV-232).....(Replaces 320 2646)	1	320 3275	
Dole (192-197 Deg.) 62 Thru 65 10-80 (V8).....(Replaces 320 3274)	1	320 4586	
Thompson (177-182 Deg.) 60-61 20-80: 60 10.....	1	320 1252	
Thompson (177-183 Deg.) 60-61 01 (LHE).....	1	320 1253	

GASKET, Thermostat To Housing

60 Thru 64 01: 65 01 (LHE)(OHV-196): 60 Thru 64 10 (OHVC): 60 Thru 65 10-20-80 (V8).....	1	310 8869	
61 Thru 64 10 (OHVA).....	1	316 0163	

2. 102 HOUSING, Thermostat

60 Thru 64 01: 65 01 (LHE)(OHV-196): 60 Thru 62 10 (OHVC): 60 Thru 65 10-80 (V8).....	1	314 4687	
61 Thru 64 10 (OHVA).....	1	315 9948	
63-64 10 (OHVC-196).....	1	316 6619	
65 01 (OHV-199)(OHV-232): 64 10 (OHV-232): 65 10 (Six): 65 80 (OHV-232)...	1	317 2305	

ATTACHING PARTS

Thermostat Housing To Cylinder Head

SCREW, Machine..... 60 Thru 64 01: 65 01 (LHE)(OHVC-196): 60 Thru 62 10 (OHVC).....(Replaces 800 0068)	17.626	1	400 0987	
STUD..... 65 01 (2-5/8" OHV-199)(2/5/8" OHV-232): 64 10 (2-5/8" OHV-232): 65 10 (2-5/8" Six): 65 80 (2-5/8" OHV-232).....	1	317 2316	#
STUD..... 65 01 (1-1/2" OHV-199)(1-1/2" OHV-232): 64 10 (1-1/2" OHV-232): 65 10 (1-1/2" Six): 65 80 (1-1/2" OHV-232).....	1	317 2315	
BOLT, Hexagon..... 65 10 (Six-WAE-Notes 2. 016-9 And 2. 003-3).....	17.038	1	G180079	NA
WASHER, Plain..... 65 01 (OHV-199)(OHV-232): 61-62 10 (OHVA): 63-64 10 (OHV-196): 65 10 (Six): 65 80 (OHV-232).....	17.814	2	G120393	NA
WASHER, Lock..... 65 01 (OHV-199)(OHV-232): 61-62 10 (OHV): 63-64 10 (OHV-196): 65 10 (Six): 65 80 (OHV-232)....	17.820	2	G120214	
WASHER, Lock..... 65 10 (Six-WAE-Notes 2. 016-9 And 2. 003-3).....	17.822	1	G138485	NA
NUT, Hexagon..... 65 01 (OHV-199)(OHV-232): 64 10 (OHV-232): 65 10 (Six): 65 80 (OHV-232).....	17.406	2	G120368	

Thermostat Housing To Manifold

SCREW, Machine..... 60 Thru 65 10-20-80.....(Replaces 800 0068)	17.626	2	400 0987	
---	--------	---	----------	--

GASKET, Thermostat Housing

60 Thru 62 01: 60 Thru 62 10 (OHVC): 60 Thru 62 20-80.....	1	312 8233	
61 Thru 64 10 (OHVA).....	1	316 0164	
63-64 01: 63 Thru 65 10-80 (V8): 65 01 (LHE)(OHV-196): 63-64 10 (OHVC-196)	1	317 1856	
65 01 (OHV-199)(OHV-232): 64 10 (OHV-232): 65 10 (Six): 65 80 (OHV-232)...	1	317 2314	

CAP, Thermostat Housing (Less Heater)

65 01 (OHV-199)(OHV-232): 64 10 (OHVC-232): 65 10 (Six): 65 80 (OHV-232)...	1	316 0337	
---	-------	---	----------	--

CLAMP, Thermostat Housing Cap (Less Heater)

65 01 (OHV-199)(OHV-232): 64 10 (OHVC-232): 65 10 (Six): 65 80 (OHV-232)...	17.108	1	320 3077	
---	--------	---	----------	--